

The USB flash drive included with your camera contains the Cheetah CamConfig software GUI for configuring and controlling your Cheetah 3G HD-SDI camera.

The software is compatible with the following versions of Microsoft Windows 32-bit and 64-bit operating systems: Windows 7, Windows 8 and 8.1, and Windows 10.

1. Before Installing the Configuration Software:

1. Insert the USB flash drive in your computer.
2. Open **File Explorer** and locate the flash drive.
3. Double click the **flash drive**.
4. Drag and drop the **Cheetah . . . _x_x_x_xxxx.exe** file to your desktop.

IMPORTANT: If an older version of the configuration software is on your computer, you must remove it. The software installation process will do this for you, or you can remove the software before beginning the installation. To remove it yourself:

1. Open **Control Panel** on your computer.
2. Select **Programs and Features**.
3. Find **Cheetah Pregius CamConfig** and select **uninstall**.

2. Installing the Programming Software GUI:

1. Double click the **Cheetah . . . _x_x_x_xxxx.exe** file you placed on your desktop.
2. If a Security screen appears, click **Ok** to continue.
3. When the Welcome screen appears, click **Next**.
4. On the License screen, click **I Agree** to accept the terms.
5. Follow the on-screen instructions until complete.
6. A shortcut icon for opening the GUI will appear on your desktop.

For information, updates, and downloads, visit www.imperx.com